

### Product cleaning & care guidelines

These guidelines are provided to help you maintain your equipment properly and prevent any damage. We have a large range of lighting products, each made with different materials and with different finishes. Use of incompatible cleaning chemicals can adversely affect the finish and physically damage the metal and plastic parts of the DARAY product, invalidating its warranty.

Please ensure these instructions are passed to the persons responsible for cleaning and that they are followed before each use.

#### Manufacturers recommended cleaning method:

1. Turn off the power to the light, and where possible, unplug the mains socket.
2. Remove noticeable contamination. Pay special attention to the light head and handle.
3. Ensure the equipment is surface-cleaned and disinfected using an appropriate, non-abrasive cleaning agent (see recommended list below).
4. Dry all surfaces thoroughly with a clean cloth and check for damaged surfaces, discolouration and/or contamination.

**NOTE:** Some DARAY products feature our BioProtect<sup>®</sup> antimicrobial coating on painted finishes. This is designed to assist with infection control and is not a replacement for cleaning.

**CAUTION:** Our products are NOT waterproof. The equipment and accessories (included chargers and battery packs) MUST NOT at any point be saturated, to prevent water ingress. Use a damp cloth or saturated wipe if necessary. All electrical safety guidelines should be followed.

Any damage caused as a result of not following these guidelines will void any product warranty.

#### Below is a partial list of recommended surface agents:



- Cavicide<sup>™</sup> products
- Isopropyl alcohol-based cleaners (<40% alcohol)
- Ethyl alcohol-based cleaners (<40% alcohol)
- Lysol<sup>®</sup> disinfectant
- Other non-bleach and non-abrasive disinfectants or cleaners

#### DO NOT USE agents containing the following:



- Organic, mineral and oxidizing acids (min. pH value 8.5)
- Bases (max. acceptable pH value 8.5)
- Oxidation agents (eg. Hydrogen Peroxide)
- Halogens (chlorine, iodine, bromide)
- Aromatic/halogenized hydrocarbons
- Bleach-based cleaners (eg. Clorox<sup>™</sup>, Sterilox<sup>™</sup>)
- Abrasive cleansers (eg. Comet Cleaner<sup>™</sup>)
- Acetone-based cleaners (eg. nail polish remover, Goo-off<sup>™</sup>)
- MEK (Methyl Ethyl Ketone)



If you are unsure of whether you are using the correct cleaning fluids on your DARAY equipment, please feel free to get in touch with us for advice.

Edison House, Robian Way, Swadlincote, Derbyshire DE11 9DH  
Tel: 0800 804 8384 info@daray.co.uk

**DARAY<sup>®</sup>**  
www.daray.com